



USER MANUAL



YOUR CELL PHONE

INSERT SIM CARD

The phone is a Dual SIM mobile phone allowing you to use the facility of two networks.

To insert USIM/SIM card(s):

1. Switch off the mobile phone and remove the rear cover and battery.
2. Insert the USIM/SIM card correctly in the card slot(s).
3. Finally insert the battery and put the rear cover back on, check it is pressed correctly. Turn the device on.
4. To manage USIM/SIM cards follow [Settings]-[SIM cards].

INSERT MEMORY CARD

1. Power off the mobile phone, then remove the rear cover and battery.
2. Insert the memory card into the slot.
3. Finally insert the battery and put the rear cover back on, check it is pressed correctly. Turn the device on.

With this device use only compatible, certified in EU, microSD/microSDHC memory cards. Incompatible memory cards may damage the card or the device and corrupt the data stored in the card.

USING THE TOUCH SCREEN

You can use the touch screen in the following ways:

Touch: acts on items on the screen, such as application and settings icons, to type letters and symbols using the onscreen keyboard, or to press onscreen buttons.

Touch and hold: touch and hold an item on the screen until an action occurs.

Drag: touch and hold an item and move your finger on the screen until you reach the target position.

Swipe or slide: quickly slide your finger across the surface of the screen, (without dragging an item). For example, slide the screen up or down to scroll a list.

Double-tap: tap quickly twice on a webpage, map, or other screen to zoom. For example, double-tap a section of a webpage in Browser to zoom that section to fit the width of the screen. You can also double-tap to control the Camera zoom, in Maps, and in other applications.

Pinch: in some applications you can zoom in and out by placing two fingers on the screen at once and pinching them together (to zoom out) or spreading them apart (to zoom in).

Rotate the screen: on most screens, the orientation of the screen changes as you rotate it. You can turn this feature on and off.

IEVIETOJĪET SIM KARTI

Telefons atbalsta divu SIM karšu darbību, kas ļauj vienlaicīgi izmantot divu dažādu tīklu pakalpojumus.

Lai ievietotu USIM/SIM karti (kartes):

1. Ieslēdziet mobilo telefonu, noņemiet aizmugurējo pārsegu un izņemiet bateriju.
2. Pareizi ievietojiet USIM/SIM karti taj paredzētajā vietā.
3. Ievietojiet bateriju un uzlieciet atpakaļ aizmugurējo pārsegu, pārbaudiet vai tas ir nofiksējies. Ieslēdziet ierīci.
4. Lai pārvaldītu USIM/SIM kartes dodieties [Iestatījumi]-[SIM kartes].

IEVIETOJĪET ATMIŅAS KARTI

1. Ieslēdziet mobilo telefonu, noņemiet aizmugurējo pārsegu un izņemiet bateriju.
2. Ievietojiet tam paredzētajā slotā atmiņas karti.
3. Ievietojiet bateriju un uzlieciet atpakaļ aizmugurējo pārsegu, pārbaudiet vai tas ir nofiksējies. Ieslēdziet ierīci.

Šajā ierīcē izmantojiet tikai atbilstošas, sertificētas EU, microSD/microSDHC atmiņas kartes. Neatbilstošas atmiņas kartes var sabojāt karti vai ierīci, kā arī bojāt kartē glabātos datus.

SKĀRIENJŪTĪGĀ EKRĀNĀ IZMANTOŠANA

Varat izmantot skārienjūtīgo ekrānu šādos veidos:

Pieskāriens: lai aktivizētu kādu programmu, nospiestu ekrāna taustiņu vai ievadītu rakstzīmi, izmantojot ekrāna tastatūru, pieskarīties attiecīgajam elementam.

Pieskarīties un turiet nospiestu: pieskarīties un turiet vienību, līdz notiek darbība.

Velciet: pieskarīties un turiet vienību, pārvietojot pirkstu pa ekrānu, līdz sasniedzat vēlamu atrašanās vietu.

Slidiniet: ātri pārslidiniet pirkstu pāri ekrāna virsmai (neizvēloties vienību). Piemēram, ritiniet ekrāna saturu uz augšu vai leju, lai apskatītu sarakstu.

Pieskarīties divreiz: ātri noklikšķiniet uz mājaslapas, kartes vai cita ekrāna, lai to pietuvinātu. Piemēram, divreiz noklikšķiniet uz mājaslapas pārliukprogrammā, lai izvēlēto sadaļu pielīdinātu ekrāna izmērā. Varat arī pieskarīties divreiz, lai kontrolētu kameras pietuvinājumu, kartes un citas aplikācijas.

Savilkšana: dažās aplikācijās iespējams pietuvināt un attālināt, novietojot uz ekrāna reizē divus pirkstus un velkot tos kopā (lai attālinātu) vai projām vienu no otra (lai pietuvinātu).

Ekrāna rotācija: ekrāna novietojums mainās, kad to pagriežat. Šo funkciju iespējams ieslēgt un izslēgt.

USING THE PHONE'S BUTTONS

The phone's buttons and soft buttons offers a lot of functions and shortcuts.

- Menu key.** Press: Opens a context menu related with current screen or Application.
- Home key.** Press: Opens the Home screen. Press and hold: Opens recently used applications.
- Back key.** Press: Opens the previous screen you were working on.

CONNECT TO NETWORKS AND DEVICES

Your phone can connect to a variety of networks and devices, including Wi-Fi, GPRS, Bluetooth, devices, such as headsets. You can also transfer files to/from your PC through the data cable.

Access to mobile data

To configure your Internet:

1. To turn on and manage your mobile data go to [Settings]-[Wireless & Networks]-[Data usage] switch to your sim card, turn on cellular data.
2. To change or check access point names of your operator go to [Settings]-[Wireless & Networks]-[More]-[Cellular networks]-[Access Point Names].

APN settings are provided automatically in SIM card. If any problems appear to connect to mobile data connection, please, check your operators APN settings in their Web page or contact your operator directly.

Access Internet via Wi-Fi

To browse the Internet via Wi-Fi:

1. Go to: [Settings]-[Wi-Fi], turn it on.
2. Next, select the Wi-Fi connection listed under Wi-Fi networks. If the Wireless access point is secured, it may be required to enter a password to access the network.

Pair With Bluetooth Devices

1. Go to: [Settings]-[Bluetooth] to turn it on. Your phone scans and displays the Bluetooth devices in range.
2. Tap Search for Devices. Also set Bluetooth preferences from here.
3. Touch the ID of the other device in the list in Settings to pair them. If you are prompted for a password, enter the password as suggested on the devices to be paired.

TELEFONA TAUSTIŅU IZMANTOŠANA

Skārienjūtīgajiem taustiņiem telefona apakšējā daļā ir piesaistītas sekojošas funkcijas.

- Izvēlnes taustiņš:** Nospiežot atver izvēlni, kas saistīta ar konkrētajā brīdī izmantoto aplikāciju vai lietotni.
- Mājas taustiņš:** Nospiežot atver sākuma ekrānu. Nospiežot un pieturot - atver nesen izmantotās aplikācijas.
- Atpakaļ:** Nospiežot atgriež iepriekšējā ekrānā.

SAVĪENOJUMI AR TĪKLIEM UN CITĀM IEKĀRTĀM

Telefons var savienoties ar dažādiem tīkliem un iekārtām, ieskaitot Wi-Fi, GPRS, Bluetooth ierīcēm (piemēram bezvadu austiņām), mobilo datu apraidei. Tāpat ir iespējams pārsūtīt dokumentus vai failus no/uz datoru, izmantojot datu kabeli.

Savienojums ar mobilo internetu

Lai pieslēgtos internetam:

1. Dodieties uz [Iestatījumi]-[Bezvadu pakalpojumi un tīkli]-[Datu savienojums] pārslēdzieties uz sim karti un ieslēdziet Mobilos datus.
2. Lai izmainītu vai pārbaudītu savu datu pieejas punktu dodieties: [Iestatījumi]-[Bezvadu pakalpojumi un tīkli]-[Vairāk]-[Mobilie tīkli]-[Piekļuves punktu nosaukumi].

Pēc noklusējuma Piekļuves punktu nosaukumi un to iestatījumi ir nodrošināti SIM kartē. Ja rodas problēmas mobilo datu piekļuvei, pārbaudiet Piekļuves punktu iestatījumus izmantotā operatora mājas lapā, var arī sazināties ar savu operatoru.

Pieejā bezvadu internetam (Wi-Fi)

Lai izmantotu Wi-Fi:

1. Dodieties uz [Iestatījumi]-[Bezvadu pakalpojumi], tad izvēlieties [Wi-Fi].
2. Ieslēdziet Wi-Fi, izvēlieties Wi-Fi savienojumu no pieejamajiem Wi-Fi tīkliem. Ja pieejamais bezvadu tīkls ir aizsargāts, var tikt pieprasīts ievadīt paroli, lai piekļūtu bezvadu internetam.

Savienojumi ar Bluetooth ierīcēm

1. Dodieties uz [Iestatījumi]-[Bluetooth], lai to ieslēgtu. Jūsu ierīce meklēs un parādīs apkārtne pieejamās Bluetooth ierīces.
2. Izvēlieties Meklēt iekārtas. Uzstādiet Bluetooth nosacījumus arī no šejienes.
3. Sarakstā uzspiediet uz otras iekārtas ID, lai tās savienotu. Ja tiek jautāta parole, ievadiet pareizo paroli, kas parādās uz abām ierīcēm.

HEALTH AND SAFETY PRECAUTIONS

SAR Compliance

Your phone is designed not to exceed the limits of emission of radio waves recommended by international guidelines.

SAR (specific absorption rate) is the measurement of body-absorbed RF quantity when the phone is in use. SAR value is ascertained according to the highest RF level generated during laboratory tests.

The SAR value of the phone may depend on factors such as proximity to the network tower, use of accessories or other accessories.

The highest SAR value of the device at the head and body are 0.08 W/kg respectively averaged over 10 g of human tissue.

SAR Recommendations

Use a wireless hands-free system (headphone, headset) with a low power Bluetooth emitter.

Make sure the cell phone has a low SAR.

Please keep your calls short and use SMS whenever more convenient. This advice applies especially to children, adolescents and pregnant women.

Prefer to use your cell phone when the signal quality is good.

People having active medical implants should preferably keep the cell phone at least 15 cm away from the implant.

Maintain a preferable distance of 15 mm from the device.

World Health Organization (WHO) Advice

Organizations such as the World Health Organization and the US Food and Drug Administration have stated that if people are concerned and want to reduce their exposure they could use a hands-free device to keep the phone away from the head and body during phone calls, or reduce the amount of time spent on the phone.

TECHNICAL SPECIFICATIONS

FREEDOM M303|QUAD CORE 1.3GHz|ANDROID 6.0

Device size: 144.6x72x9.3 mm

Weight (with battery): 165 g

SIM: 2 Micro-SIM, Dual Standby

4G Bands: LTE 1/3/7/20

3G Frequency: WCDMA 900/2100 MHz

2G Frequency: GSM 850/900/1800/1900 MHz

Chipset Platform: MTK 6737, 32-bit

CPU: Quad Core 1.3GHz, Cortex-A53

GPU: Mali-T720MP1, 650MHz

Operating system: Android 6.0 Marshmallow

Display: 5" IPS HD 720x1280 px

Touch panel: 2 touch, Capacitive

Camera: 8MP AF (back) + 5MP (front)

Video: 720p@30fps

Supports: GPRS, WCDMA, LTE, GPS, FM

WLAN: Wi-Fi 802.11 a/b/g/n, Wi-Fi Direct, hotspot

Bluetooth: v4.0, A2DP, EDR, LE

Sensors: Proximity, Light, Accelerometer

Internal memory: 2GB RAM + 16GB ROM

Memory card: microSD/MicroSDHC, up to 32GB

Battery: Li-ion 2000mAh

Standby time: 2G/3G/4G up to 270h

Talk time: 2G up to 20h, 3G/4G up to 7h

A/C adapter: 5V 1A

Headset: 3.5 mm

USB: MicroUSB v2.0

TAVS MOBILĀIS TĀLRUNIS

Micro USB izeja Audio 3.5 mm izeja



Izvēlnē Atpakaļ

Mājas

